

Xerox Device TLS Support

July 15, 2020

© 2020 Xerox Corporation. All rights reserved. Xerox®, AltaLink®, ColorQube®, DocuPrint®, Phaser®, PrimeLink®, VersaLink®, WorkCentre®, Brenva®, FreeFlow®, Free Flow® Accxes® are trademarks of Xerox Corporation in the United States and/or other countries. BR30918

Other company trademarks are also acknowledged.

Document Version: 1.0 (July 2020).

Introduction

Xerox single function printers and multifunction devices use the Transport Layer Security (TLS) cryptographic protocol to provide end-to-end network security for communications between the device and other nodes on the network, whether those nodes are other devices, servers, PCs, web browsers, etc. There are several versions of this protocol and the version used is negotiated between the server and the Xerox device. In general, this means the highest version that both the Xerox device and the IT product interfacing with the Xerox device support will be used but this may not always be the case. It is possible to disable a lower version by configuration changes at the Xerox device.

This document describes currently supported TLS versions by the various Xerox devices.

Note: This information is valid for the latest available Software for each product. Xerox will update the tables below as changes are made to products. If you wish to have a specific TLS version supported by a Xerox device, please contact Xerox Customer Support.

Contents

1. Monochrome Hardware Products	1-1
2. Color Hardware Products.....	2-3
3. Production / Light Production Products.....	3-5

1. Monochrome Hardware Products

Xerox Monochrome Product Models	TLS 1.0	TLS 1.1	TLS 1.2
Xerox® AltaLink® B8045/B8055/B8065/B8075/B8090 Series Multifunction Printer	√	√	√
DocuPrint® 425/850, 500/1000, 525/1050CF			
Phaser® 3010/3040 Printer			
Phaser® 3052 Printer	√	√	√
Phaser® 3155/3160 Printer			
Phaser® 3250 Printer	√		
Phaser® 3260 Printer	√	√	√
Phaser® 3300 MFP	√		
Phaser® 3315/3325 Printer	√		
Phaser® 3320 Printer	√	√	√
Phaser® 3330 Printer	√	√	√
Phaser® 3600 Printer	√	√	√
Phaser® 3610 Printer	√	√	√
Xerox® Phaser® 3635 MFP	√	√	√
Phaser® 4500 Printer	√		
Phaser® 4510 network printer	√	√	
Xerox® Phaser® 4600/4620 Printer	√	√	√
Xerox® Phaser® 4622	√	√	√
Phaser® 5335 Printer	√* Needs network card		
Xerox® Phaser® 5550 Printer	√	√	√
Xerox® WorkCentre® M35/M45/M55 & Xerox® WorkCentre® Pro 35/45/55	√		
Xerox® WorkCentre® / Xerox® WorkCentre® Pro 232/238/245/255/265/275	√		
Xerox® WorkCentre® 3025 Multifunction Printer	√	√	√
Xerox® WorkCentre® 3045 B/NI Multifunction Printer			
Xerox® WorkCentre® 3210/3220 Multifunction Printer	√		
Xerox® WorkCentre® 3215/3225 Multifunction Printer	√	√	√
Xerox® WorkCentre® 3315 Multifunction Printer	√		
Xerox® WorkCentre® 3325 Multifunction Printer	√	√	√

Xerox Monochrome Product Models	TLS 1.0	TLS 1.1	TLS 1.2
Xerox® WorkCentre® 3335/3345 Multifunction Printer	√	√	√
Xerox® WorkCentre® 3550 Multifunction Printer	√	?	?
Xerox® WorkCentre® 3615 Multifunction Printer	√	√	√
Xerox® WorkCentre® 3655 Multifunction Printer	√	√	√
WorkCentre® 4250 MFP	√	√	√
WorkCentre® 4260 MFP	√	√	√
Xerox® WorkCentre® 4265 Multifunction Printer	√	√	√
Xerox® WorkCentre® 5030/5050 Multifunction Printer	√		
Xerox® WorkCentre® 5135/5150 Multifunction Printer	√		
Xerox® WorkCentre® 5222/5225/5525A/5230/5230A Series Multifunction Printer	√		
Xerox® WorkCentre® 5225/5230	√		
Xerox® WorkCentre® 5325/5330/5335 Series Multifunction Printer	√	√	√
Xerox® WorkCentre® 5632/5638/5645/5655/5665/5675/5687 Series Multifunction Printer	√		
Xerox® WorkCentre® 5740/5745/5755/5765/5775/5790 Series	√	√	√
Xerox® WorkCentre® 5845/5855/5865/5875/5890 Series Multifunction Printer	√	√	√
Xerox® WorkCentre® 5945/5955 Multifunction Printer	√	√	√
Xerox® WorkCentre® Bookmark 40/55 copier/printer	√		
Xerox® WorkCentre Pro® 65/75/90	√		
Xerox® VersaLink® B400 Printer	√	√	√
Xerox® VersaLink® B405 Multifunction Printer	√	√	√
Xerox® VersaLink® B600/B610 Printer	√	√	√
Xerox® VersaLink® B605/B615 MFP	√	√	√
Xerox® VersaLink® 7025/7030/7035 Series Multifunction Printer	√	√	√
Xerox B1022/B1025 Multifunction Printer	√	√	√
Xerox M20i	√		

2. Color Hardware Products

Xerox Color Product Models	TLS 1.0	TLS 1.1	TLS 1.2
Xerox® AltaLink® C8030/C8035/C8045/C8055/C8070 Series Color Multifunction Printer	√	√	√
ColorQube 8570/8870	√	√	√
ColorQube 8580/8880 Printer	√	√	√
ColorQube 8700/8900 Multifunction Printer	√	√	√
ColorQube 8870	√	√	√
ColorQube® 9201/9202/9203	√		
ColorQube® 9301/9302/9303	√	√	√
Xerox® Phaser® 6000/6010 Printer			
Xerox® Phaser® 6015 Multifunction Printer			
Xerox® Phaser® 6020 Printer	√	√	√
Xerox® Phaser® 6022 Printer	√	√	√
Phaser® 6125 Color Laser Printer			
Xerox® Phaser® 6128/6128 MFP			
Xerox® Phaser® 6130 Color Printer	√* Needs network card		
Xerox® Phaser® 6140 Printer	√		
Xerox® Phaser® 6180/6180 Color Printer	√		
Xerox® Phaser® 6280 Color Printer	√	√	√
Xerox® Phaser® 6360 Color Printer	√	√	
Xerox® Phaser® 6500 Printer	√	√	√
Xerox® Phaser® 6510 Color Printer	√	√	√
Xerox® Phaser® 6600 Printer	√	√	√
Xerox® Phaser® 6700 Printer	√	√	√
Xerox® Phaser® 7100 Printer	√	√	√
Xerox® Phaser® 7500	√	√	√
Phaser® 7750			
Phaser® 7760			
Xerox® Phaser® 7800 Printer	√	√	√
Phaser® 8400			
Phaser® 8560			

Xerox Color Product Models	TLS 1.0	TLS 1.1	TLS 1.2
Xerox® Phaser® 8860 Color Multifunction Printer			
Xerox® WorkCentre® 6015 N/NI			
Xerox® WorkCentre® 6025 Multifunction Printer	√	√	√
Xerox® WorkCentre® 6027 Multifunction Printer	√	√	√
Xerox® WorkCentre® 6400	√		
Xerox® WorkCentre® 6505 Multifunction Printer	√	√	
Xerox® WorkCentre® 6515 Color Multifunction Printer	√	√	√
Xerox® WorkCentre® 6605 Multifunction Printer	√	√	√
Xerox® WorkCentre® 6655 Color Multifunction Printer	√	√	√
Xerox® WorkCentre® 7120/7125/7132 Series Multifunction Printer	√	√	√
Xerox® WorkCentre® 7220/7225 Multifunction Printer	√	√	√
Xerox® WorkCentre® 7232/7242 Multifunction Printer	√ OpenSSL L 1.0.1p (TLS)	√	√
Xerox® WorkCentre® 7328/7335/7345/7346 Series Multifunction Printer			
Xerox® WorkCentre® 7425/7428/7435 Series Multifunction Printer	√	√	
Xerox® WorkCentre® 7525/7530/7535/7545/7556 Series MFP	√	√	√
Xerox® WorkCentre® 7655/7665/7675 Series Color Multifunction Device	√		
Xerox® WorkCentre® 7755/7765/7775 MFP	√		
Xerox® WorkCentre® 7830/7835/7845/7855 Series Multifunction Printer	√	√	√
Xerox® WorkCentre® EC7236 / EC 7256		√	√
Xerox® WorkCentre® 7970 Color Multifunction Printer	√	√	√
Xerox® WorkCentre Pro® C2128/C2336/C3545	√		
Xerox® VersaLink® C400 Color Printer	√	√	√
Xerox® VersaLink® C405 Color Multifunction Printer	√	√	√
Xerox® VersaLink® C500 Color Printer	√	√	√
Xerox® VersaLink® C505 Color Multifunction Printer	√	√	√
Xerox® VersaLink® C600 Color Printer	√	√	√
Xerox® VersaLink® C605 Color Multifunction Printer	√	√	√
Xerox® VersaLink® C7000 Color Printer	√	√	√
Xerox® VersaLink® C7020/C7025/C7030 Series Color Multifunction Printer	√	√	√
Xerox® VersaLink® C8000/C9000 Color Printer	√	√	√

3. Production / Light Production Products

Xerox Color Product Models	TLS 1.0	TLS 1.1	TLS 1.2
EFI Print Servers	√	√	√
Free Flow® Print Servers	√	√	√
Free Flow® Accxes® Print Servers			
Xerox® 4110/4590 Enterprise Printing System	√	√	
Xerox® 4112/4127 CP & Enterprise Printing System	√	√	
Xerox® 4135 Printing System			
Xerox® 4595 Digital Copier Printer	√	√	
Xerox® 4635 MX Printer			
Xerox® 6204 Wide Format Printer Copier	√		
Xerox® 6279 Wide Format Printer	√		
Xerox® 650/1300 Continuous Feed Printer	√		
Xerox® 6604/6605 Wide Format	√		
Xerox® 6662 Wide Format	√		
Xerox® 700/700i Digital Color Press			
Xerox® 770 Digital Color Press			
Xerox® 8825 Wide Format	√		
Xerox® 8830 Wide Format	√		
Xerox® Brenva® HD Production Inkjet Press	√	√	√
Xerox® CilPress™ 325/500 Production Inkjet System	√	√	√
Xerox® Color 550/560/570 Printer	√	√	√
Xerox® Color 800/1000 Press	√	√	√
Xerox® Color 800i/1000i Press	√	√	√
Xerox® Color 8250 Production Printer	√	√	√
Xerox® Color C60/C70 Printer	√	√	√
Xerox® Color C75 Digital Press	√	√	√
Xerox® Color J75 Digital Press	√	√	√
Xerox® D95/D110/D125 Printer	√	√	√
Xerox® D95/D110/D125/D136 Copier/Printer	√	√	√
Xerox® PrimeLink® B9100 Series	√	√	√