

Mini Bulletin XR18G

Xerox® Phaser® 3600

SPAR Release 1.70.03.10 SMP3R10

Bulletin Date: March 1, 2018

Purpose

This Bulletin is intended ONLY for the specific security problem identified below. The problem identified has been rated a criticality level of IMPORTANT. This release includes OpenSSL 1.0.2j

Includes the fix for:

- OpenSSL updates to mitigate OpenSSL Pointer Arithmetic vulnerability (CVE-2016-2177)

Software Release Details

If your software is higher or equal to the versions listed below no action is needed.

Otherwise, please review this bulletin and consider installation of this version.

Model	Phaser 3600
System SW version	OS: 1.70.03.10
Link to SW update	Available here

Installation Instructions

NOTE: This firmware contains a digital signature. Once this firmware is installed on a Phaser 3600 you will not be able to downgrade to previous unsigned versions of firmware.

In order to upgrade your firmware, verify Software Upgrade is Enabled:

- Access the web page of the device.
- Go to Properties > Security > Upgrade Management.
- If Sys Admin credentials are set, key in when prompted. [Default state for Software Upgrade = disabled. The 'Enabled' check box is empty.]
- Check the Enable box in order to allow software upgrades.

A pop up will display "Your Selections have been modified successfully." For best security leave this control set to disabled after upgrading your software. The control must be set to enabled prior to doing a software upgrade.

CentreWare Internet Services (CWIS) Procedure for upgrading firmware on a Phaser 3600 printer:

- Copy the Phaser 3600 firmware file to your computer. If the file is in a .zip format, unzip the file.
- Open Internet Explorer or other Browser application. Type in the IP address of the Phaser 3600 to be upgraded (example: "http://12.345.67.89/"). Press the Enter key to connect to the printer.

- Select the Print button. Select File Download under Print options (left side of screen).
- Within the “File Download” screen, select “Browse” to access the location on your computer where you have placed the firmware file. Select the file and Enter.
- Select the blue button below the filename window to begin the file download to the printer. A “pop-up” window will be displayed showing the file download status.
- Once the file has been downloaded to the printer, the screen will show “End of Download”. Select OK to close the message window.
- The firmware file will be installed on the printer.
- You may print a Configuration Page to confirm the new firmware file version has been installed. To do this from the browser window select “Print -> Print Configuration Pages”, select “Printer Configuration Page” then the blue button. Please refer to the “Firmware Version” title on the printed configuration page.
- You can now close the CWIS window.