

Xerox Product Security Mini Bulletin XR15AZ Phaser 4600/4620 Release SMP2R23 35.004.54.000

Release Date: Dec 16, 2015



Purpose

This Bulletin is intended ONLY for the specific security problems identified below. The problems identified has been rated a criticality level of **IMPORTANT**. This release includes OpenSSL 1.0.2d.

Includes fixes for:

- Logjam Vulnerability in OpenSSL (CVE-2015-0400). A vulnerability in TLS protocol versions 1.2 and earlier allows man-in-the-middle attacks to occur against vulnerable systems that support older key exchange methods. Xerox has included a non-vulnerable version of OpenSSL in the software version available below.
- Fix for TCP vulnerability in VxWorks (CVE 2015-3963).

Software Release Details

If your software is higher or equal to the versions listed below no action is needed. Otherwise, please review this bulletin and consider installation of this version.

Model	Phaser 4600/4620
System SW version	35.004.54.000
Link to update	Available here

Save the file to a convenient location on your workstation. Unzip the file if necessary.

Installation Instructions

Manual upgrade over the network via Xerox CentreWare Internet Services (CWIS):

1. Open the web browser from your Workstation.
2. Enter the *IP Address* of the machine in the Address bar and select **[Enter]**.
3. Click on the **[Properties]** tab.
4. Click on the Maintenance arrow on the left side bar and select Software Upgrade and make sure it is enabled.
5. Click on the Maintenance arrow on the left side bar and select Firmware Upgrade.
6. Click **[Browse]**.

7. Locate and select the software upgrade file obtained earlier. The firmware file will have an extension **.hd**.
8. Click **[Install Software]**.

Note 1: Please use ASCII characters only in file path.

Note 2: Software Installation will begin several minutes after the software file has been submitted to the machine. Once Installation has begun all Internet Services from this machine will be lost, including this Web User Interface. The installation progress can be monitored from the Local UI

Note 3: If the printer does not take the flash and start the flash process power cycle the printer and try again.